# ニップル治具
# NIPPLE CHUCK

## 取扱説明書　INSTRUCTION MANUAL

【ご使用前に必ず本書をお読みください。】
【Read through this manual carefully before using the machine】

IM0701

# ニップル治具

## 安全にご使用いただくために　SAFETY PRECAUTIONS

このたびは、ニップル治具をお買い上げいただきましてありがとうございます。

● この取扱説明書は、お使いになる方に必ずお渡しください。
● ご使用前に必ず本書を最後までよく読み、確実に理解してください。
● 適切な取扱いで本機の性能を十分発揮させ、安全な作業をしてください。
● 本書は、お使いになる方がいつでも取り出せるところに大切に保管してください。
● 本機を用途以外の目的で使わないでください。
● 商品が届きましたら、ただちに次の項目を確認してください。
　・ ご注文の商品の仕様と違いはないか。
　・ 輸送中の事故等で破損、変形していないか。
　・ 付属品等に不足はないか。

万一不具合が発見された場合は、至急お買い上げの販売店、または当社営業所にお申し付けください。
（本書記載内容は、改良のため予告なしに変更することがあります。）

Thank you for choosing our NIPPLE CHUCK.

● This Instruction Manual must be retained by the user of this machine.
● Read this Instruction Manual carefully and completely before use and thoroughly understand the usage, capacity, cautions, and easy repairs for correct operation.
● Handle the machine properly to make full use of its functions for safe work.
● After reading the instructions, save this manual so that you can read it when necessary.
● Use the machine for the intended application only. It will do a better job and be safer at the rate for which it was designed.
● Upon receiving the machine, check the following.
　・ Check that the machine is built conforming to the specifications stated in your order.
　・ Check the overall machine for any damage or deformation caused in transit due to accidents or other reasons.
　・ Check that all items and accessories delivered.

In case any discrepancy is found, immediately report the fact to the shop you purchased or our sale office.
(The contents of this manual are subject to change without prior notice.)

# NIPPLE CHUCK

## 製品の構成　COMPONENTS OF THE MACHINE

### 各部の名称　Main Parts

### 仕　様　Specifications

| 品　名<br>Model | ニップル治具 PT1/2" ～ 2" セット<br>NIPPLE CHUCK |
|---|---|
| コード No.<br>Code No. | 01810 |
| 標準付属品<br>Standard Accessories | キャップ（1/2"・3/4"・1"・1.1/4"・1.1/2"・2"）、キャップハンドル、シャフト、ケース<br>Nipple Cap（1/2"・3/4"・1"・1.1/4"・1.1/2"・2"）、Nipple Chuck Handle、Nipple Holder、Case |

# 使用方法 HOW TO OPERATE - NIPPLE CHUCK

① パイプの片方を規格どおりにねじを切り、必要な長さに切断してください。

② シャフトをハンマーチャックにチャッキングしてください。

③ キャップにねじをはめ込み、キャップをシャフトに取付けてねじを切ります。

④ ねじ切りが終了後、キャップハンドルにてキャップをゆるめ、ねじを取外します。

※ ニップル加工範囲：1/2" ～ 2"

※ キャップの種類:1/2"、3/4"、1"、1.1/4"、1.1/2"、2"

① Cut the pipe at constant length.

② Insert the Nipple Holder in the hammer chuck.

③ Tighten the pipe to the nipple cap and install it to the NIpple Holder.

④ Start to thread cutting. Remove the pipe by nipple chuck handle after finished screw thread cutting.

※ Working range: 1/2" ～ 2"

※ Nipple cap sizes: 1/2"、3/4"、1"、1.1/4"、1.1/2"、2"

本　　社　名古屋市北区上飯田西町 3-60　☎(052)911-7165

| | | | |
|---|---|---|---|
| 東京支店 | ☎(03)3635-2511 | さいたま営業所 | ☎(048)653-4121 |
| 名古屋支店 | ☎(052)911-7161 | 横浜営業所 | ☎(045)441-4331 |
| 大阪支店 | ☎(06)6743-3991 | 広島営業所 | ☎(082)238-1277 |
| 札幌営業所 | ☎(011)704-4391 | 福岡営業所 | ☎(092)474-4137 |
| 仙台営業所 | ☎(022)258-6811 | | |

海外事業所

アサダ・タイランド社 （バンコク）
台湾浅田股份有限公司 （台北）
アサダ・アーロンコ マシナリー社 （クアラルンプール）
上海浅田進出口有限公司 （上海）
アサダトレーディング USA （オレゴン州・ユージン）

工　場

犬山工場 （愛知県・犬山市）
第一精工株式会社 （松阪市）
アサダ・マシナリー社 （バンコク）

URL http://www.asada.co.jp　E-mail:sales@asada.co.jp

コード No. IM0006　PRINT No. 070700A